

AT A GLANCE.

Covered items⁴

	Platinum	Gold	Powertrain
Engine	●	●	○
Turbocharger/Supercharger	●	●	●
Transmission	●	●	○
Transfer Case	●	●	○
Drive Axle	●	●	●
Electric/Hybrid Vehicle Components	●	●	●
Steering	●	●	●
Braking system	●	●	
Electrical (basic)	●	●	
Air Conditioner	●	●	
Fuel Delivery	●	●	
Front and Rear Suspension	●	●	
Cooling	●	●	
Shock Absorbers, Struts, Mounts	●		
Supplemental Restraint Systems	●		
Emission Components	○		
All Vehicle Components³ (other than a list of exclusions) ⁴	●		
Additional benefits.			
24 Hour Roadside Assistance	●	●	●
Software Updates ⁴	●	●	●

● Included with your plan⁴

○ Less coverage than Gold⁴

Please see your authorized BMW Retailer for full protection plan details, or contact us at www.BMWfinance.ca or 1-800-3000-BMW.

- Costs or expenses for any physical items needed or provided during a covered emergency service call including, but not limited to, fuel and replacement keys, are the customer's responsibility.
- Towing covered for up to 100 kilometres per incident due to a mechanical breakdown, to your nearest BMW Retailer or Service Centre.
- Replacement parts will be BMW-approved parts.
- Please consult your contract for specific service plan details, including additional limitations and exclusions.
- Terms for new vehicles start from the vehicle's in-service date. Terms for pre-owned vehicles within factory warranty start on the vehicle's in-service date. Terms for pre-owned vehicles out of factory warranty start on the contract date and vehicle's odometer reading at the date of purchase. Available Terms vary by vehicle model. Certain limitations may apply.

BMW MBP is optional and is not insurance. All transactions related to BMW MBP are governed solely by the provisions of the BMW MBP contract ("Contract"). This document provides general information about the BMW MBP and should not be solely relied upon when purchasing services. Please refer to your Contract for details of terms, conditions, and specific service plan details, including limitations and exclusions. Services may vary by province. Not all vehicle models may be eligible for a service contract. Please see your Retailer for more information.

The Obligor/Provider of the Contract is BMW Canada Inc., 50 Ultimate Drive, Richmond Hill, ON L4S 0C8, 1-844-611-6490. The Administrator of the Contract is LGM Financial Services Inc., Suite 400, 1021 West Hastings Street, Vancouver, BC V6E 0C3.

©2024 BMW Canada Inc. "BMW", the BMW logo, BMW model designations and all other BMW related marks, images and symbols are the exclusive properties and/or trademarks of BMW AG, used under license.

BMW-MBP-B2C-0124-R2E

WITH YOU
EVERY MOMENT™



MECHANICAL BREAKDOWN PROTECTION. BMW Financial Services

For New and Pre-Owned vehicles.

PROGRAM HIGHLIGHTS.

Consider these reasons to purchase BMW Mechanical Breakdown Protection today:

- Lock-in future repair costs with today's money.
- Quality BMW-approved parts for your vehicle.
- Repairs performed by BMW Certified Technicians.
- Coverage throughout Canada and continental U.S.
- Fully refundable within 30 days of purchase.
- Valuable additional benefits including rental vehicle (\$60 per day, for up to five days) and 24 hour roadside assistance commence at time of purchase.^{1,2}
- Fully transferable to next private owner.⁴
- Maximize resale value.

Please see your authorized BMW Retailer for full protection plan details, or contact us at www.BMWfinance.ca or 1-800-3000-BMW.



EASE THE BURDEN OF MECHANICAL REPAIRS.

BMW Mechanical Breakdown Protection (MBP) helps protect you from unanticipated expenses. It will deliver services beyond your factory warranty, with service plan options for repairs that include parts and labour.

With BMW Mechanical Breakdown Protection, you'll receive genuine BMW-approved parts³ and service for your vehicle. Service is available at all authorized BMW Retailers and Service Centres in Canada.

Coverage can be purchased to suit your needs, for up to 7 years/200,000 km on new vehicles or 4 years/80,000 km on pre-owned vehicles.⁵

LEVELS OF COVERAGE.⁴

Platinum

Ultimate protection for total peace of mind. All components are covered except for a select list of exclusions.

Gold

Extensive coverage across the powertrain and many other critical vehicle components that can be costly to repair.

Powertrain

Coverage for major powertrain components on your BMW.

Exclusions apply: Mechanical breakdowns covered by your vehicle's manufacturer's warranty, or caused by accident, collision, vandalism, weather-related conditions, lack of maintenance, or pre-existing conditions.⁴

ADDITIONAL BENEFITS.

Besides exceptional coverage to protect your vehicle, BMW MBP comes complete with an array of additional benefits.

24 hour roadside assistance¹

- ✓ Towing²
- ✓ Lock-out service
- ✓ Winching
- ✓ Battery jump start
- ✓ Fuel delivery

Rental car while your vehicle is being repaired (\$60 per day, for up to five days).

Transfer

If you sell your vehicle, BMW MBP is transferable to the next private owner for a \$100 fee.

Cancellation

Can be cancelled by you during the first 30 days.⁴

UNEXPECTED REPAIRS MAY BE CLOSER THAN THEY APPEAR.

Mechanical breakdowns can happen when you least expect them and are often costly to repair. With BMW Mechanical Breakdown Protection on board, you will enjoy:

- The security of knowing your BMW is covered for many component failures and mechanical breakdowns.
- Maximized re-sale of your BMW with coverage that is transferable to another private owner.
- 24 Hour roadside assistance to help get your BMW back on the road as quickly as possible.



Covered items⁴

	Platinum	Gold	Powertrain
Engine (and all internally lubricated parts contained within the engine)			
Cylinder Block, Cylinder Head(s)	●	●	●
Pistons, Piston Rings & Wrist Pins	●	●	●
Connecting Rods & Bearings	●	●	●
Crankshaft	●	●	●
Camshaft	●	●	●
Camshaft Bearings, Case & Followers	●	●	●
Timing Gears, Guides, & Tensioner	●	●	●
Timing Cover & Housing	●	●	●
Rocker Arms, Shafts, Bearings	●	●	●
Cylinder Head Valves, Guides, & Lifters	●	●	●
Springs, Seals, Retainers, & Seats	●	●	●
Push Rods	●	●	●
Oil Pump	●	●	●
Oil Pump Housing	●	●	●
Harmonic Balancer	●	●	●
Intake & Manifolds	●	●	●
Valve Covers	●	●	●
Engine Mounts	●	●	●
Water Pump	●	●	●
Seals & Gaskets	●	●	●
Timing Chain or Belt	●	●	●
Engine Oil Cooler	●	●	●
Crankshaft Pulley	●	●	●
Turbocharger			
Turbocharger Housing & all Internal Parts	●	●	●
Seals & Gaskets	●	●	●
Transmission (automatic or standard and all internally lubricated parts)			
Transmission Case	●	●	●
Torque Converter	●	●	●
Flywheel/Flex Plate	●	●	●
Vacuum Modulator	●	●	●
Transmission Mount	●	●	●
Seals & Gaskets	●	●	●
Electronic Shift Control Unit	●	●	●
Ring Gear	●	●	●
Servo & Governor Covers	●	●	●
Hydraulic Clutch Master & Clutch Slave Cylinders	●	●	●
Factory Installed Transmission Cooler & Lines	●	●	●
Hydraulic Lines & Fittings	●	●	●
Transfer Case (and all internally lubricated parts)			
Transfer Case Housing & All Internal Parts	●	●	●
Seals & Gaskets	●	●	●
Mounts	●	●	●
Vacuum or Electric Control Motors	●	●	●
Drive Axle (and all internal parts contained within the Drive Axle)			
Front & Rear Drive Axle Cases	●	●	●
Locking Hubs	●	●	●
Axle Shafts	●	●	●
Drive Shafts & Yokes	●	●	●
Universal Joints	●	●	●
Centre Support Bearing	●	●	●
Constant Velocity Joints	●	●	●
Wheel Bearings/Hub Assemblies	●	●	●
Axle Bearings	●	●	●
Four-Wheel Drive Actuator	●	●	●
Differential Cover	●	●	●
Seals & Gaskets	●	●	●
Steering			
Rack & Pinion Steering Gear (all internal parts)	●	●	●

	Platinum	Gold	Powertrain
Power Steering Pump	●	●	●
Steering Knuckle	●	●	●
Steering Column Assembly	●	●	●
Seals & Gaskets	●	●	●
Control Valve	●	●	●
Tie Rod Ends & Boots	●	●	●
Cooler	●	●	●
High Pressure Hoses	●	●	●
Return Hoses	●	●	●
Lines & Fittings	●	●	●

Brakes			
Master Cylinder	●	●	●
Vacuum/Assist Booster	●	●	●
Disc Brake Calipers	●	●	●
Wheel Cylinders	●	●	●
Proportioning Valve	●	●	●
ABS Hydraulic Control Unit	●	●	●
Accumulator & Pump	●	●	●
ABS Electronic Control Module	●	●	●
Seals & Gaskets	●	●	●
Backing Plates	●	●	●
Self Adjusters & Return Springs	●	●	●
Brake Hydraulic Lines & Fittings	●	●	●
Wheel Speed Sensors	●	●	●

Electrical			
Alternator Regulator	●	●	●
Voltage Regulator	●	●	●
Starter Motor	●	●	●
Solenoid & Drive	●	●	●
Engine Compartment Wiring Harness	●	●	●
Electronic Powertrain Control Module	●	●	●
Electronic Ignition Module	●	●	●
Ignition Switch	●	●	●
Front & Rear Window Wiper Motor(s)	●	●	●
Stop Lamp Switch & Headlamp Switch	●	●	●
Turn Signal Switch & Multifunction Switch	●	●	●
Heater/A.C. Blower Speed Switch	●	●	●
Manual Heater/A.C. Control Assembly	●	●	●
Horns	●	●	●
Washer Pump & Switch	●	●	●
Crank Angle Sensor	●	●	●
Ignition Coil	●	●	●
Gauges	●	●	●
Cruise Control System	●	●	●
Power Window Motor(s) & Power Window Switch	●	●	●
Rear Defroster Switch	●	●	●
Power Door Lock Actuator & Switch	●	●	●

Electric / Hybrid Vehicle Components⁴			
Electric/Hybrid Battery	●	●	●
Hybrid Starter Generator	●	●	●
Hybrid Power Control Unit	●	●	●
Automatic Transmission including Traction Motor	●	●	●

Air Conditioner			
Condenser & Compressor	●	●	●
Clutch & Pulley	●	●	●
Air Conditioning Lines & Hoses	●	●	●
Evaporator & Expansion Valve	●	●	●
Idler Pulley & Idler Pulley Bearing	●	●	●
High/Low Compressor Cut-Off Switch	●	●	●
Receiver/Dryer	●	●	●

	Platinum	Gold	Powertrain
Refrigerant in conjunction with the repair or replacement of a component listed above	●	●	●

Seals & Gaskets	●	●	●
-----------------	---	---	---

Fuel Delivery			
Fuel Pump & Relay	●	●	●
Fuel Distributor & Injectors	●	●	●
Vacuum Pump	●	●	●
Metal Fuel Delivery Lines	●	●	●
Seals & Gaskets	●	●	●
Fuel Injection Sensors & Control Units (except Oxygen Sensor)	●	●	●
Fuel Pressure Regulator	●	●	●

Front & Rear Suspension			
Upper/Lower Control Arms & Shafts	●	●	●
Bearings & Bushings	●	●	●
Upper Ball Joints	●	●	●
Lower Ball Joints	●	●	●
Radius Arm & Bushings	●	●	●
Torsion Bars, Mounts & Bushings	●	●	●
Stabiliser Bar, Links & Bushings	●	●	●
Spindle & Spindle Support	●	●	●
Shock absorbers, Struts, & Mounts	●	●	●

Cooling			
Engine Cooling Fan, Motor & Relay	●	●	●
Water Pump & Pulley	●	●	●
Fan Clutch	●	●	●
Serpentine Belt Tensioner	●	●	●
Radiator/Heater Core	●	●	●
Thermostat	●	●	●
Blower Motor	●	●	●
Hot Water Control Valve	●	●	●
Seals & Gaskets	●	●	●

Other			
Airbags	●	●	●
Heated Seat Elements	●	●	●
Blindspot Collision Detection System	●	●	●
Heater / Vent Control Actuator	●	●	●
Wire Harnesses	●	●	●
Hands-free Tailgate Sensor	●	●	●
Factory-installed USB Ports	●	●	●
Touchscreen Display	●	●	●
Coil Springs	●	●	●
Window Regulators	●	●	●
Windshield Washer Reservoir & Spray Nozzles	●	●	●
Rear Park Distance Monitoring System	●	●	●
Door Latch Assembly & Lock Cylinders	●	●	●
O2 Sensor	●	●	●

All Vehicle Components³
(other than a list of exclusions)⁴

PLATINUM PLAN NON-COVERED COMPONENTS.⁴

- Accessory items**
Cell Phones, Electronic Keyless Entry Transmitter (Key Fob), Non-Factory Audio Equipment, Tire Pressure Sensors.
- Maintenance related items**
Exhaust and Emission Systems, Batteries, Clutch Assembly, Brake Rotors and Drums, Friction Clutch Disc and Pressure Plate, Light Bulbs, Fuses, Throw Out Bearing, Door and Trunk handles, Safety Restraint Systems.
- Cosmetic items**
Glass, Lenses, Sealed Beams, Weather Strips, Trim Items, Moldings, Bright Metal, Chrome, Upholstery and Carpet, Paint, Outside Ornamentation, Bumpers, Body Sheet Metal and Panels, Frame and Structural Body Parts.